



Installation Instructions

P/N BP-004 Subpanel

Suspension Kit

The BP-004 Kit is designed to support the installation of subpanels, hinge panels, or dead-fronts into the base of the PolyGuard Series enclosures.

Using this system, you can install multiple panels inside the enclosure, maximizing the space available for component installation.

The kit includes 4 (four) mounting pads, 4 (four) #8 Allen Screws, and 1 (one) #8 Allen Screw Wrench.

To install the mounting pads, slide the pad into the track found in the corners of the enclosure base. Slide the pad to the location desired. Insert the Allen Screw into the middle channel using the wrench provided, and screw the allen screw in until it is even with the mounting pad. This ensures full engagement.

An alternative method is to install a #10-3/8" screw through the hole on the bottom of the mounting pad into the channel.

Please call us with any questions or comments.

